

SCONES:

PREPARATION: PLACE FROZEN SCONES ON PARCHMENT LINED BAKING SHEET. SCONES ARE DONE WHEN CENTER SPRINGS BACK WHEN TOUCHED LIGHTLY. COOL BEFORE REMOVING FROM BAKING SHEET.

Baking Instructions

CONVECTION* 325°F 24 - 29 M FULL SHEET

STANDARD 375°F 29 - 34 M *ROTATE PAN HALFWAY THROUGH BAKE TIME

Cinnamon Rolls

STORE FROZEN UNTIL READY TO USE

Place dough on a silicone papered or greased pan 3 1/2 - 5 inches apart. (If used for caramel rolls, place rolls on top of caramel ingredients.)

Cover and place in the refrigerator overnight to thaw.

Remove from the refrigerator and let rise until rolls are 2 1/2 times their original size.

Bake in a preheated 375 degrees F conventional oven for 16 - 19 minutes or 325 degrees F convection oven for 15 - 18 minutes.

Remove from the oven. (Turn caramel rolls upside down on the pan.)

Ice rolls when cool.